



FORCE EDGE CONNECT

Machine Repository

Version 230406

Manual



Document: Manual - FORCE EDGE
CONNECT Machine Repository



Release date: 2023-04-06



Document version: 1




Author: FORCAM GmbH

Content

1	Concept	3
2	Description System Components	4
2.1	Definition of Templates	4
2.2	Overview list of assets	5
3	System architecture	6
4	Navigation Area	7
4.1	Templates	8
4.1.1	Open template	9
4.2	List of all assets	10
4.3	Connected EDGE-Instance	11
4.3.1	Add an EDGE instance	12
4.4	User management	13
4.5	Licensing	15
4.6	Sorting table entries	16
5	Creation of a template	17
5.1	Creating a template without connected asset	17
5.2	Creating a template from a connected asset	18
5.3	Configuration Wizard	19
5.3.1	① Basic information	19
5.3.2	② MDC controller configuration	19
5.3.3	③ Signal	21
5.3.4	④ Composition	22
5.3.5	⑤ DNC configuration	24
5.3.6	⑥ Deployment	25
5.3.7	⑦ Overview	26
6	Appendix	27
6.1	Document-Convention	27
6.2	Abbreviations and terms	27
6.3	List of supported plug-ins	28
6.4	Script functions	31
6.5	Table of figures	34

1 Concept

 FORCE EDGE CONNECT is a prerequisite to use the FORCE EDGE CONNECT Machine Repository.

FORCE EDGE CONNECT (hereafter only referred to as EDGE CONNECT) Machine Repository provides the user with the ability to define templates for connecting any asset. These can either be created via the Machine Repository (MR) configuration wizard or derived from assets already connected via EDGE CONNECT. In this way, templates offer a simple solution, especially when expanding a machine park with new, similar assets. The template-supported connection of assets significantly reduces the effort required for digitization. The product enables every company to easily create, manage and use templates for the standardized connection of the same asset types.

The use of templates for connecting the same assets ensures that identical information is derived on the basis of asset signals. This creates direct comparability of assets and makes it possible to transfer asset-related measures.

As part of the traceability of individual changes to a template, a new template version is created in MR each time a change is made. The history of a template can be viewed directly in MR. Individual versions can be restored manually.

The MR's asset list provides an overview of all assets connected in the EDGE instances. The accumulated knowledge on the MR can be distributed across plants so that all plants can have the same templates available. You can bring your plants to the same level of digitization with ease.

2 Description System Components

This chapter describes the following components of the FORCAM EDGE Machine Repository in more detail:

- Definition of Templates
- Overview Asset List

2.1 Definition of Templates

The template is a connection template for digitizing a specific type of asset. It does not contain any asset specific information such as IP address or serial number of an asset.

The template can contain the following asset type specific connectivity information:

- Template name and description
- Asset type and classification
- Manufacturer and model
- Controller type (PLC/PLC) and bus type description
- Signal definition
- Script for signal interpretation
- DNC configuration

By providing the general tethering information of an asset type, the effort to digitize an asset of the same type is significantly reduced. When using a template in EDGE Configuration, the tethering information is automatically applied in the Asset Configuration Wizard.




Figure 1: Template administration in MR

2.2 Overview list of assets

An asset is a collective term for elements that can be linked to the EDGE CONNECT (e.g. machines, sensors, databases, etc.). The asset list displays the assets of all linked EDGE instances that are connected to the EDGE CONNECT Machine Repository. In the Machine Repository, templates can be derived from the assets linked in the EDGE instances.




Figure 2: Overview of the asset park

3 System architecture

EDGE CONNECT Machine Repository is an optional extension to EDGE CONNECT. The MR is a standalone application that communicates with EDGE CONNECT via clearly defined interfaces. Therefore, the MR can be installed and deployed in the customer's IT infrastructure as well as in a cloud environment.

For example, several EDGE instances can be supplied by the MR. FORCAM thus makes a significant contribution to digitization in industry and focuses on the cost-efficient connection of assets across plants.




Figure 3: Architectural Structure EDGE CONNECT Machine Repository

4 Navigation Area

Templates can be managed in the navigation area of the MR. It is also possible to get an overview of the connected assets and the connected EDGE instances. You can also manage the users and their rights. This chapter covers **templates, list of all assets, connected EDGE instances, user management** and **licensing** and then explains the sorting behavior of **table entries**.




Figure 4: Calling up the home area

4.1 Templates

On the start page of the MR, an overview of the templates already created is displayed. Among other things, templates can be created, imported, copied and deleted here. Information about the individual templates is displayed, such as the highest version number or the use of an MDC/-DNC control.

OVERVIEW

Templates

Templates (28)

1 2




NAME	LATEST VERSION	MANUFACTURER	MODEL	MDC	DNC	DESCRIPTION
search...						
Hermle C42	2	Hermle	C42			Basic Template for Hermle C42. Script for State Events. 3
DMG CTX Beta 20000	1	DMG	CTX beta 2000			DMG CTX Beta 20000 with OPC UA. Script for State Events.
MAZAK_Integrex_200_IV_ST	2	MAZAK	Integrex 200-IV ST			MAZAK Integrex 200-IV ST via MT-Connect. Script for State Events.
Boehringer DUS 1000	2	Boehringer	Boehringer			Boehringer DUS 1000. Script for State Events.
Alzmetall GS1000	2	Alzmetall	GS1000			Alzmetall GS 1000 with Sinumerik 840D. Script for State Events.
Basic Template for						

Figure 5: Template-Overview

- (1) Importing a template
- (2) Creation of a template without attached asset (see chapter 5.1)
- (3) Settings menu of the template:
 - Open template
 - Export template
 - Copy template
 - Delete

4.1.1 Open template

When opening the template, details such as asset type, version, signals, MDC control and DNC plugin are displayed. The template can be edited as desired. Each change to the template results in a new version being created. The version is incremented by 1. The history provides transparency and supports the tracking of changes. It is possible to manually reset the template to any previous version. Under the item Deployment you can track for which EDGE instances the template was released with the respective version.

-  The Version with the highest number is the current one.
-  Clicking Edit opens the same configuration wizard as in chapter 5.3.
-  It is not possible to change the template name afterwards.

TEMPLATE DETAIL

Hermle C42

Edit

Description:
Basic Template for Hermle C42. Script for State Events.

Asset Type:
Machine

Asset class:
Milling machine

Version:
2

Signals:
12

Manufacturer:
Hermle

Model:
C42

MDC controller:
Heidenhain

DNC Plugin:

HISTORY

DEPLOYMENT

TEMPLATE NAME	VERSION	DATE	AUTHOR
search...			
Hermle C42	2	21/09/2022, 09:01:05	bmeissner

Figure 6: Template Details

4.2 List of all assets

The list of all assets shows an overview of all assets of the EDGE instances that are connected to the MR. This gives you an overview of your machinery.

OVERVIEW
Asset List

Assets(36)

1 2 3 4 5 6

ASSET NAME	ASSET TYPE	EDGE INSTANCE	ASSIGNED TEMPLATE	CONFIGURATION STATUS	SYNC DATE
OPC-UA_Test_2	Machine	EDGE 1		In Progress	New
Script_Vorlage	Machine	EDGE 2		In Progress	Updated
Schneider_Electric_Link 150_IEM3150	Sensor	EDGE 1		Completed	Updated
Enisco_Soft_PLC	Machine	EDGE 1	Enisco_Soft_PLC	Completed	Updated
WAGO_750_862_Test	Machine	EDGE 1		In validation	Updated
KUKA_SoftPLC	Machine	EDGE 1		In Progress	31/01/2023
ek_machine_1	Machine	Acad_Ersatz	Fischertechnik	In validation	31/01/2023 - out of sync

Figure 7: Overview list of all assets

- (1) Name of the EDGE instance to which the asset is attached.
- (2) Configuration status of the asset:
 - In Progress: The configuration is not yet complete and is to be continued at another time.
 - In Validation: The configuration of the asset is to be checked for errors and consistency.
 - Completed: The configuration is fully completed. It is recommended to generate a template from the asset only in this status.
- (3) All assets that are not yet synchronized are passed to MR.
- (4) Date of the last synchronization:
 - New: assets that have been added but not yet transferred to MR
 - Not synchronized: Configuration is not accessible, last update status is displayed
- (5) Individual assets are transferred to MR
- (6) Creation of a template from an asset (see chapter 5.2)

i Only when the asset is transferred to the MR, the note “New” disappears.

4.3 Connected EDGE-Instance

Overview and management of the already linked EDGE instances with the Machine Repository. Details of the EDGE instances are displayed here, such as name, status, and number of EDGE nodes. In addition, you can connect new EDGE instances to the MR here.





Figure 8: Overview linked EDGE Instances

- (1) Headline with number of linked EDGE instances.
- (2) Adds a new EDGE instance
- (3) Name of the EDGE instance
- (4) Settings menu of the instance:
 - Edit
 - Delete
- (5) Status of the connected instance
 - Connected
 - Disconnected
- (6) Number of EDGE-Nodes

4.3.1 Add an EDGE instance

EDGE instances can be added in the MR in a few steps. Multiple EDGE instances can be connected to the MR.



Link with new EDGE instance

EDGE Configuration

URL *

http://192.168.1.100:8080

Name *

EDGE 3

EDGE Configuration Login

Please authorize yourself by entering a valid user of the EDGE Configuration you would like to connect to.

Username *

EDGE@user.de

Password *

Cancel Apply

Figure 9: Dialog for adding a new instance

To add a new EDGE instance:

1. Click **+ EDGE** in the instance overview.
2. In the subsequent dialog, add all mandatory fields:
 - URL:
Consist of http + IP address + port. Only one EDGE instance can be added per URL.
 - Name: Appears in the instance overview as the title of the instance.
3. Enter **username** and **password** from the EDGE configuration belonging to the desired EDGE instance.
4. Apply.

4.4 User management

Users can be created for the EDGE CONNECT Machine Repository in the user administration. The users can be assigned appropriate rights depending on their role in the company. These are linked to different functions such as managing templates or configurations. Existing user accounts can also be edited subsequently.

- i** If the rights of a logged-in user have been changed, they become effective immediately after a new login. If the user does not log in again, it can take up to 30 minutes until the change is active.




Figure 10: User management in EDGE CONNECT Machine Repository

To create a new user:

1. Click on **+ user**
2. Enter the user name in the subsequent dialog
3. Optional: enter **mail-address, first and last name**
4. Select **language**
5. Optional: activate **darkmode**
6. Set desired password
Must be at least 8 characters long, consist of upper and lower case letters and contain at least one number and one special character.
The following special characters are allowed:
! " # \$ % & ' () * + , - . / : ; < = > ? @ [\] ^ _ ` { | } ~
7. Assign user rights (see below)
8. Save

- i** A user cannot be created again with the same data.

Create User

×

Username *

Felix_Schneider

Email *

felix.schneider@mail.com

First name

Felix

Last name

Schneider

Language

English

Darkmode

☐

New password *

Confirm password *

User rights:

Usermanagement

☒

Manage Templates

☒

Deploy Templates

☒

Manage Configuration

☒

Cancel

Save

Figure 11: Dialogue for creating a new user

Table 1: User rights of EDGE CONNECT Machine Repository

User right	Description
User administration	The user can call the user administration, create new users and assign/remove rights.
Manage templates	The user can call, create, copy, delete, import and export templates
Distribute templates	When configuring a template, the user can deploy the template to the different EDGE instances.
Manage configuration	The user can connect, edit and delete EDGE instances.

4.5 Licensing

Under Licensing, licenses can be imported and viewed.




Figure 12: Licensing and overview

- (1) A new license can be uploaded as a file or entered directly as a key.
- (2) The license information includes type and status of the license, model, maintenance, validity and other data.

4.6 Sorting table entries

Most pages in EDGE CONNECT Machine Repository display data in the form of tables. In order to offer the familiar ease of use that you know from other table tools, the sorting function of columns has been used here as well: You can sort the columns alphabetically ascending or descending.




Figure 13: Alphabetical sorting of columns

5 Creation of a template

This chapter describes how to create a template. Basically, a distinction is made between two cases:

- Creation of a template without a connected asset (see chapter 5.1)
- Creation of a template from a connected asset (see chapter 5.2)

5.1 Creating a template without connected asset

The user has the possibility to freely configure a template for an asset type. A guided configuration wizard allows you to create a template in a few steps (see chapter 5.3). Here MDC/DNC controls are configured, machine signals are defined and the deployment for a template is specified.

 The steps in the configuration wizard are the same as in chapter 5.3.




Figure 14: Create template

To add a new template:

1. Click on Home in the upper area.
 Or
 Click on Home in the navigation area.
2. Click on **+ Templates** (see above).
 → The following dialog guides you through the next seven steps to configure a template (see chapter 5.3).

5.2 Creating a template from a connected asset

The creation of a template by deriving an already connected asset is done with little effort. The mask of the configuration wizard is preset with the information of the selected asset. The asset-specific data, such as IP address or serial number, is not transferred.




Figure 15: Create a template from a connected asset

To add a new template based on an asset:

1. Click the **list of all assets** in the navigation pane.
2. Click the **Template icon** in the right pane on the desired asset (see above).

- ❗ The steps in the Configuration Wizard are the same as in chapter 5.3.
- ❗ The pre-filled configuration fields in the template can be customized manually as desired.
- ❗ FORCAM recommends generating a template from the asset when the configuration status is completed.

5.3 Configuration Wizard

This section describes the individual steps of the configuration wizard.

- i** If a step is completed, it is highlighted in blue in the top bar. Clicking on a completed step returns to it.

5.3.1 ① Basic information

Basic information about the template is specified here, such as name or asset type. In addition, it is determined whether an MDC or a DNC control is to be configured.

- !** The template name cannot be changed after the complete configuration.

Figure 16: Configuration Wizard - Basic Information

1. Enter template name.
2. Optional: Enter description, asset type, classification, manufacturer and model number.
3. Activate the button Configure MDC and/or Configure DNC.
4. Click on Next.

5.3.2 ② MDC controller configuration

Describes the way in which communication with the asset takes place. The **controller type defines the type of controller to communicate with**. The bus type is a specific communication protocol of the controller type. An overview of the current FORCAM plug-ins is listed in section 6.3.

- i** This step is only available if **Configure MDC** was activated in step ①.


The screenshot shows a configuration wizard for an MDC controller. At the top, there is a horizontal navigation bar with seven steps: 1. BASIC INFORMATION, 2. MDC CONTROLLER (highlighted with a blue underline), 3. SIGNAL, 4. SCRIPT, 5. DNC CONFIGURATION, 6. DEPLOYMENT, and 7. OVERVIEW. Below the navigation bar, the main heading is "MDC controller configuration". There are three form fields: a text input for "Description", a dropdown menu for "Controller type *" with "Node-RED" selected, and another dropdown menu for "Bus type *" with "Node-RED (see manual for connection details)" selected. Each dropdown menu has a small downward arrow icon on the right side.


Figure 17: Configuration Wizard - MDC controller

1. Optional: Enter description of the controller.
2. Choose **Controller-Typ** and **Bus-Typ**.
3. Click on **Next**.

5.3.3 ③ Signal

This step defines which signals are read out from the controller. Depending on the configuration of the MDC control from step ②, different listings of the signal types are displayed. The Data Lake can be used to record and save all data. Data Lake storage can be switched on & off per signal. Units can be specified for the individual signals (e.g. degrees Celsius or liters a minute), and scaling factors can also be set. The scaling factor makes it possible, for example, to infer temperature by the resistance recorded on an asset.

 Signals can be imported or exported by means of a CSV file.

 If the **Active** switch for the signal is deactivated, it cannot be used in ⑤ script.




Figure 18: Configuration Wizard – Signal

1. Click the + icon.
2. Select the **type**, enter the **signal name** and optionally activate the Data Lake switch.
3. Specify **plugin-specific signal parameters**.
4. Optional: enter **units & scaling and description**.
5. Click on **Next**.

5.3.4 ④ Composition

In this step, the recorded signals are interpreted, from which logical conclusions about the asset behavior can be drawn. As a result, measurement values, maintenance information and production states are available. In this step ④ **Composition**, conditions for the interpretation of the signals are defined. There are two ways to enter these conditions: In the **SCRIPT** section, text-based code is displayed and edited (see Figure 20), whereas graphical blocks can be used in the **GRAPHIC** section (see Figure 19). These are programming blocks/modules that can be put together and connected, similar to the individual pieces of a puzzle. The advantage of this modular system is that you can create the commands even if you are new to programming in general. On the left side of the screen, all available function categories are listed, divided and sorted by color. Drag-and-drop can be used to move the required blocks to the editing area on the right and place them in the correct order. This is where the actual asset logic is defined.

⚠ If you use list a list, don't forget to empty this list.

⚠ It is not possible to switch from SCRIPT to GRAPHIC mode. If the graphic was converted to a script, the script can be edited in the SCRIPT area but it cannot be reset to the block variant.




Figure 19: Add asset - GRAPHIC mode

- ① The annex of this manual contains sample scripts and script functions (see section 6.4).
- ① For a detailed description of the individual function categories of the blocks, see the **Graphical Composition** manual.



Figure 20: Add asset - SCRIPT mode

1. Enter the desired script into the central input field.
2. Optional: Check the script's validity at the top right of the SCRIPT screen.
3. Click **Next**.

⚠ The script must be error-free. You can only proceed to the next configuration step if the script has no errors.

ℹ The script editor can be set to full screen via the maximize icon.

5.3.5 ⑤ DNC configuration

Possibility to configure a DNC control. Determines the communication how a NC file should be transferred to the asset. FORCAM supports many common controllers on the market and is constantly working to expand their availability. An overview of current plug-ins is listed in section 6.3.

① This step is only available if Configure DNC has been activated in step ①.

The screenshot shows the 'DNC configuration' step of a 7-step wizard. The steps are: 1. BASIC INFORMATION, 2. MDC CONTROLLER, 3. SIGNAL, 4. SCRIPT, 5. DNC CONFIGURATION (active), 6. DEPLOYMENT, and 7. OVERVIEW. The main content area is titled 'DNC configuration' and contains four fields: 'Upload timeout (sec)' with a value of 10, 'Download timeout (sec)' with a value of 10, 'Plugin for machine configuration *' with a dropdown menu showing 'FileHandler', and an 'Auto delete' toggle switch which is currently turned off.


Figure 21: Configuration Wizard – DNC Configuration

1. Optional: Enter **upload** and **download timeout**.
2. Enter the **plug-in for the machine configuration**.
3. Optional: Activate the switch for automatic deletion.
4. Click on **Next**.

① If the switch for Automatic deletion is active, the file is automatically deleted after the asset is read out. Otherwise, the files accumulate on the asset and manual deletion is required.

5.3.6 ⑥ Deployment

The deployment specifies the EDGE instances to which the template is to be released.

 Only the EDGE instances that are connected to the MR are listed.




Figure 22: Configuration Wizard – Deployment

5.3.7 ⑦ Overview

Summary of the previous configuration from all steps and lists the MDC/DNC controls, signals and deployment. Confirmation creates the template, with the specified configurations, and displays it on the home page as a table view. Consequently, the template is deployed to the corresponding EDGE instances. From the template, a concrete asset can now be connected in the EDGE Configuration.

1

BASIC INFORMATION

2

MDC CONTROLLER

3

SIGNAL

4

SCRIPT

5

DNC CONFIGURATION

6

DEPLOYMENT

7

OVERVIEW

Overview

TEMPLATE

Name

Schneider_Electric_Link150_IEM3150

Asset Type

Sensor

Asset class

Other

Model

Link 150 / IEM 3150

Description

CONTROLLER

MDC

Description

Controller type

Node-RED

Bus type

Node-RED (see manual for connection details)

DNC

Upload timeout (sec)

10

Download timeout (sec)

10

Plugin

FileHandler

Auto delete

inactive

SIGNALS

SIGNAL

TYPE

ActivePowerL1

STRING

ActivePowerL2

STRING

ActivePowerL3

STRING

ActivePowerTotal

STRING

CurrentAvg

STRING

CurrentL1

STRING

CurrentL2

STRING

CurrentL3

STRING

DEPLOYMENT

NAME

EDGE 1

EDGE 2

Back

Apply

Figure 23: Configuration Wizard – Overview

6 Appendix

6.1 Document-Convention

Table 2: Fonts, formatting and characters used

Conventions	Description
Boldface	Buttons and options names are written in boldface.
<i>Italics</i>	Highlighted words are in italics.
Icons	For a function that is represented by an icon, the icon is referenced as the object.
Action result	Action results are indicated by ➔.
Prerequisites	Prerequisites are indicated by ✓.
Warnings	Warnings are indicated by ⚠.
Notes	Notes are indicated by ⓘ.
Tips	Tips are indicated by ⓘ.

6.2 Abbreviations and terms

Table 3: Abbreviations and terms used

Abbreviations	Explanation
Apache Kafka	Apache Kafka is a distributed messaging system that uses the publish-subscribe method.
Asset	Generic term for all objects that EDGE CONNECT can connect (e.g. machines, sensors, databases, IT systems, etc.).
Brownfield	An existing factory or manufacturing facility that has already been built and in operation for some time. The Brownfield approach in the context of Industry 4.0 means the digital transformation of an existing manufacturing plant.
CP	Communication processor
DNC	Distributed Numerical Control: NC systems that are connected to a computer. The individual systems can be centrally supplied with NC programs and then coordinated.
IT	Information technology
Asset	In EDGE CONNECT, the asset is a partial plant according to ISA 95. If there are no other partial plants (i.e. additional physical controls), we refer to it as a plant.
MDC	Asset data connection (asset data collection)

MQTT	Message Queuing Telemetry Transport: Open network protocol for asset-to-asset (M2M) communication that enables transmitting telemetry data in the form of messages between devices, despite high delays or network limitations.
MR	Asset Repository
Northbound	A northbound interface communicates with a higher level element in a particular network component.
OT	Operational technology
POST	POST is a method which is supported by HTTP and means that a web server accepts the data contained in the body of the message requested.
PUT	The PUT method is used to update a resource available on the server. Typically, it replaces everything existing at the target URL with something else.
REST	Programming paradigm for distributed systems (collection) of independent computers that present themselves to the user as a single system.)
RESTful API	API for data exchange based on HTTP requests via GET, PUT, POST and DELETE, which is subject to the requirements or restrictions of the REST architecture.
Signal	Values read from the asset control, such as temperature, pressure or certain statuses.
Southbound	An equivalent to the northbound interface, a southbound interface communicates with lower level components.
SPS	Programmable Logical Control
UTC	Coordinated Universal Time
Wildcard	Placeholder for other characters.

6.3 List of supported plug-ins

MDC Plugins

Table 1: List of all supported asset connection variants

Name	Read	Write	Transmission type Polling/Event based
AUDI SPS	X	X	X/
CSV file exchange	X		X/
Euromap 63	X		X/
Euromap 77 (via OPC UA)	X	X	/X
FANUC	X	X	X/
FORCAM I/O Controller	X	X	/X
FORCAM I/O Controller (hardware)	X		
Heidenhain	X	X	X/

Name	Read	Write	Transmission type Polling/Event based
MAKINO Pro 3/Pro 6	X		
Mazak	X		
MCIS RPC (SINUMERIK 810D/840D/840D)	X		X/X
Modbus	X		
MQTT	X	X	/X
MT Connect	X		X/
Node-RED	X	X	/X
OKUMA	X		
Omron	X		
OPC Classic	X	X	X/
OPC UA	X	X	/X
OPC XML	X		X/
Rockwell/Allen Bradley	X	X	X/
Siemens LOGO	X	X	X/
Siemens S5 with CP	X		
Siemens S5 without CP	X		
Siemens S7 with CP	X	X	X/
Siemens S7 without CP	X	X	X/
SQL database exchange	X		X/
Weihenstephan	X		X/
Wiesemann & Theis (WUT)	X		X/

DNC plugins

Table 2: List of all supported NC asset connection variants

Name	Read	Write
COM	X	X

Heidenhain	X	X
Mazak DNC	X	X
RPC Plugin	X	X
FTP Plugin	X	X
FANUC	X	X
File Handler (File Copy)	X	X
File Handler Server	X	X
MOXA-Box	X	X
Wiesemann & Theis (WUT)		

6.4 Script functions

Application	Script function Parameters in [...] are optional	Description	Output event
Default	SendImpulse(ImpulseCount, [Reference])	Sends impulses.	Impulses
Default	SendQuantity(Quantity, [Unit], [QualityDetail], [Reference])	Sends quantity.	Quantity
Custom	SendState(State, [StatusCodesListName], [Reference])	Sends status.	State
Default	SendStateProduction([StatusCodesListName], [Reference])	Sends production status.	State
Default	SendStateStoppage([StatusCodesListName], [Reference])	Sends the stop state.	State
Default	SendSignalValue(SignalName, Value, [Unit], [Reference], [CustomerSpecificSetting], [Timestamp])	Sends the value of a signal. Data type "Long" (L) must be used for the timestamp list.	SignalValue
Default	SendSignalPackage(SignalNamesListName, ValuesListName, [UnitsListName], [Reference], [CustomerSpecificSetting], [TimestampsListName])	Sends signal values as a package. Data type "Long" (L) must be used for the timestamp list.	SignalPackage
Custom	SendGenericInformation(ParamName, ParamValue, [Reference])	Sends generic information.	GenericInformation
Helper	ListNew(ListName, DataType)	Creates a new list with the name ListName and list elements of the data type DataType (S for string, B for boolean, N for number).	-
Helper	ListAdd(ListName, Value)	Adds an element to the list.	-
Helper	ListClear(ListName)	Empties the list.	-
Helper	ListDelete(ListName)	Deletes the list.	-
Helper	GetMachineStatus()	Indicates the asset status.	-
Helper	GetMachineData(ParameterName)	Indicates asset data for the specified parameter.	-
Helper	SetParameter(ParameterName, ParameterValue)	Sets a new value for the specified parameter.	-
Helper	GetParameter(ParameterName)	Fetches the value for the specified parameter.	-
Helper	DeleteParameter(ParameterName)	Deletes the parameter.	-
Helper	DeleteAllParameters()	Deletes all parameters.	-
Helper	OFFLINE	Indicator whether the controller is offline or not.	-
Helper	IPADDRESS	The IP address of the Composition.	-

Applicat ion	Script function Parameters in [...] are optional	Description	Output event
Helper	HOSTNAME	Hostname of the Composition.	-
Helper	SQRT(args)	Root function MATH.	-
Helper	SIN(args)	Sine function MATH.	-
Helper	COS(args)	Cosine function MATH.	-
Helper	TAN(args)	Tangent function MATH	-
Helper	RISINGEDGE(args)	At the beginning the variable is FALSE, the EDGE checks if the values have changed. If this is the case, the variable is corrected to TRUE.	-
Helper	FALLINGEDGE(args)	Checks if the last inspected value was true and if it is false.	-
Helper	SUBSTRING(str, startIndex[, endIndex])	Substring of the specified string.	-
Helper	TONUMBER(str)	String to number (double), replaces comma to period in string.	-
Helper	TOSTRING(str or number[, formatSpecifier])	Specifies the format of the form width. The default formatting is used for empty strings. Width is the minimum length of the result string. Precision is the number of decimal places. If not specified, 0 is used. If the format specification starts with 0, the result string is prefixed with filled zeros. If the format specification ends with X, the number is converted to hexadecimal, using upper or lower case letters with upper or lower case x. In this case, the decimal places are always cut off.	-
Helper	LENGTH(obj)	The length of an object as a string value.	-
Helper	FORMATTIME(timeformatStr, timeOffset, [, timeunit])	<p>Formats the current time with the time unit as one of the following:</p> <p>MILLISECOND SECOND MINUTE HOUR TAG MONTH YEAR MSABSOLUTE (current time)</p> <p>"R" at Format is specified as a number in milliseconds, otherwise the format is used and the offset and time unit are used to calculate the time.</p>	-

Applicat ion	Script function Parameters in [...] are optional	Description	Output event
Helper	STDLOG(ignored, logLevel, suffixNumber, logText)	The first parameter is ignored. The log level should be W = warning, C or F = error and everything else for the debug level. The suffix number, if not 0, is added to the end of the log text as "<SuffixNumber>" with script loggers.	-
Helper	DEBUGOUT(text)	Logs the text at debug log level with parser logger.	-
Helper	COPYFILE(inFile, outFile)	Copies data from in-file to out-file. Arguments can be file paths. If successful, the last modified out-file is also updated as in-file.	-
Helper	COPYREPLACE(inFile, outFile, searchStr, replaceStr)	Copies from in-file to out-file as with function COPYFILE, replacing all incidences of search-string with replace-string.	-
Helper	ATTIME(seconds, obj)	Calculates the object every day at specified times in seconds (seconds represents time fraction of the current day in seconds).	-
Helper	FROMASCII(num)	Returns a string that has the numeric value specified as num.	-
Helper	SLEEP(ms)	Pauses the current thread for a specified time in milliseconds (ms).	-

6.5 Table of figures

Figure 1: Template administration in MR	4
Figure 2: Overview of the asset park	5
Figure 3: Architectural Structure EDGE CONNECT Machine Repository	6
Figure 4: Calling up the home area	7
Figure 5: Template-Overview	8
Figure 6: Template Details	9
Figure 7: Overview list of all assets	10
Figure 8: Overview linked EDGE Instances	11
Figure 9: Dialog for adding a new instance	12
Figure 10: User management in EDGE CONNECT Machine Repository	13
Figure 11: Dialogue for creating a new user	14
Figure 12: Licensing and overview	15
Figure 13: Alphabetical sorting of columns	16
Figure 14: Create template	17
Figure 15: Create a template from a connected asset	18
Figure 16: Configuration Wizard - Basic Information	19
Figure 17: Configuration Wizard - MDC controller	20
Figure 18: Configuration Wizard – Signal	21
Figure 19: Add asset - GRAPHIC mode	22
Figure 20: Add asset - SCRIPT mode	23
Figure 21: Configuration Wizard – DNC Configuration	24
Figure 22: Configuration Wizard – Deployment	25
Figure 23: Configuration Wizard – Overview	26